




10 2



NOTE: PRE-CUT KITS ARE NOT PRE-DRILLED.

В

Α


10

(Holes shown in this drawing are for reference only. Drilling of pilot holes are to be done by fabricator.)


*NOTE: Drill a 3/8" oversized hole for the head of the hinge screw to slip through.

DETAIL A

*NOTE: IT IS RECOMMENDED THAT THE FRAME BE ASSEMBLED ON THE BODY, THEN RATCHET STRAPPED TO CHECK FOR SQUARE, BEFORE THE FRAME IS WELDED OR MECHANICALLY FASTENED.







DETAIL B CROSS-SECTION

Drive the hinge screw down into the body so the head of the screw is under the retainer flange as shown.

TOP CROSS-SECTION

2

Ship To: Sales Order #

1

THIS DRAWING WAS CREATED AT NO CHARGE TO ASSIST YOU IN VISUALIZING OUR PROPOSAL. THE DRAWING HEREIN IS THE PROPERTY OF SIGNCOMP.
OR TO USE THIS DRAWING FOR PRODUCTION IS STRICTLY PROHIBITED AND CAN ONLY BE COPIED, REVISED OR USED FOR PRODUCTION WITH THE EXP
Project Name: Narrow Body w/ Tension Frm II & Bleed Cvr-6" Rad. Corners

| Of 1 | Size: | OF

Sign Company: K2021/86/95/4488

SBreihof

5/24/2019

4

